



EcoBlue and Economizer Training

Bob Friedman

Technical Support 1-800-264-2512 Option 3, then 1

Please have your 6 digit account number handy
when you call.

ms.techsup@carrierenterprise.com





WeatherMaker[®]
with **ecoblue**[™] technology



WeatherMaster[®]
with **ecoblue**[™] technology

ecoblue[™]  technology

New 3-6 Ton Rooftop



Vane Axial Indoor Fan System



Gas Heating / Electric Cooling Models – 48FC

| Nominal Cooling Ton Size | Cooling Stages | AHRI Efficiency (SEER) IEER |
|--------------------------|----------------|-----------------------------|
| 3 | 1 | (14.0) |
| 4 | 1 | (14.0) |
| 5 | 1 | (14.0) |
| 6 | 2 | 15.0 |

Electric Heat / Electric Cooling & Cooling Only Models – 50FC

| Nominal Cooling Ton Size | Cooling Stages | AHRI Efficiency (SEER) IEER |
|--------------------------|----------------|-----------------------------|
| 3 | 1 | (14.0) |
| 4 | 1 | (14.0) |
| 5 | 1 | (14.0) |
| 6 | 2 | 15.2 |

Larger sizes are available now on the FC's



48/50FC04-07 WeatherMaker® Single-Package Gas Heating/Electric Cooling and Electric Cooling Rooftop Units with Optional Electric Heat with Puron® Refrigerant (R-410A), 3 to 6 Nominal Tons

Product Data 02/01/2021 48-50FC-4-7-03PD



48/50FC08-16 WeatherMaker® Single-Package Gas Heating/Electric Cooling and Electric Cooling Rooftop Units with Optional Electric Heat with Puron® Refrigerant (R-410A), 7.5 to 15 Nominal Tons

Product Data 08/01/2022 48-50FC-8-16-01PD



48/50FC20-30 WeatherMaker® Single-Package Gas Heating/Electric Cooling and Electric Cooling Rooftop Units with Optional Electric Heat with Puron® Refrigerant (R-410A), 17.5 to 27.5 Nominal Tons

Product Data 08/01/2022 48-50FC-20-30-01PD




Gas Heating / Electric Cooling Models – High Efficient 48GC


| Nominal Cooling Ton Size | Cooling Stages | AHRI Efficiency SEER |
|--------------------------|----------------|----------------------|
| 3 | 2 | 16.0 |
| 4 | 2 | 16.0 |
| 5 | 2 | 16.0 |

Electric Heat / Electric Cooling & Cooling Only Models – High Efficient 50GC

| Nominal Cooling Ton Size | Cooling Stages | AHRI Efficiency SEER |
|--------------------------|----------------|----------------------|
| 3 | 2 | 16.0 |
| 4 | 2 | 16.0 |
| 5 | 2 | 16.0 |

NEW VANE AXIAL TECHNOLOGY





487382725 194388876
PG: 0060043736 SAT Prod Plan
2018/04/10 12:15:42 34742 1

Removing the blower assembly



Follow normal safety precautions

Removing the blower assembly

Disconnect the motor plug

Disconnect the Limit wires


Remove front mounting screws




Removing the blower assembly

There are 2 clips that hold tension on the back of the Axial Fan Housing.

The (3) 5/16 screws need to be loosened on both back clips to allow easy removal of the fan assembly.




The front of the fan assembly is held in place with (2) 5/16 screws, these will have to be removed to pull the fan out.



Motor Replacement



Motor Replacement



Release all four tabs holding the blue casing to the stator

Motor Replacement



Motor Replacement




Motor Replacement

Separate the rotor from the motor hub



Motor Replacement



Motor Replacement

Remove the 4 motor mounting screws



Motor Replacement

Make sure the wiring grommet is released from the Stator



Motor Replacement

Lift the stator off the motor



Motor Replacement



Motor Replacement



HD56JZ231 M3G112-EA88-F6 Made in Germany DE(H)37/18 IE4

3- 208-230VAC 50/60Hz (4.5A 1500W) @208V 4.94Nm 2530rpm IP20

VSD integrated Max Cont App HP - 1.76 @60Hz

PLUG PINOUT

| | |
|----------------------------|--------------------------|
| 1 = Power L1 BK | 7 = CTL Signal Common WH |
| 2 = Power L2 YEL | 8 = 10vdc Source OR |
| 3 = Power L3 (3ph only) BU | 9 = 0-10vdc Signal GR |
| 4 = Earth Ground GRN/YEL | |

EARL cRU[®] US E11236-40 Electronically-Protected Ins.Cl.F AO

3ph 200-230VAC 50/60Hz max.7.0A max.2300W

18370032TK




Motor Replacement




Motor Replacement

Motor alignment tab



Motor Replacement

Stator alignment slot



Motor Replacement

Make sure the motor and stator line up correctly



Install the 4 motor mounting screws

Motor Replacement

Secure the wiring grommet back into the stator



Motor Replacement

When installing the rotor on the motor you may have to use a pocket screwdriver to get the holes aligned properly



Motor Replacement

Snap the blue casing back into place making sure all 4 tabs lock in properly



Motor Replacement

Make sure the motor spins freely before installing it back into the unit



Condenser Fan



**High Efficiency Composite
Outdoor Fan**

New 3-6 Ton Rooftop






Decorative protective grille



High efficient outdoor fan motor with single and 2-speed on high efficiency models



Non corrosive precision balanced outdoor fan blade



New air flow collar to improve efficiencies

Condenser fan assembly










NEW VANE AXIAL UNITS UCB BOARD

Single Phase HK50AA055



Three Phase HK50AA058





CURRENT BOARD
(Central Terminal Board)







NEW BOARD
Unit Control Board

Low voltage safety and accessory wiring




Limit removed on later production








Manual reset limit removed



Full view of the circuit board connections






Control board outputs 2-10vdc back to the motor module to bring it on and control its speed.

10 VDC from the motor module to the control board

10 VDC common from motor module


Wiring diagram



Plug location in the blower section




Close up of the motor plug




48FC07 with a 3 Phase blower motor

View of the control board test pins



Outputs from the control board to the motor are read at these test pins




10 VDC positive is supplied from the motor

10 VDC Common from the motor

Control signal 2-10 VDC output from the control board to the motor

If the 10 Volt DC voltage power supply circuit from the motor has failed the motor will have to be replaced.

If the motor spins freely you can test the motor with a 9 volt battery



If the motor runs with the battery, there is a temporary fix you can use if the replacement motor is not readily available.

If the motor runs with a 9 Volt battery, as a temporary fix you can use a 24 VAC to 12 VDC power adapter until the replacement motor comes in.



BeElion 24V AC to 12V DC Convertor, 1.5 Amp Supply Current Power Adapter and 2.1 x 5.5mm DC Power Male Plug Pigtail for...




★★★★☆ ~ 106

\$13⁵⁹

✓prime

FREE delivery **Wed, Sep 28** on \$25 of items shipped by Amazon

Installing the temporary voltage adapter.



To use the voltage adapter, follow these steps:

- Turn off the power to the unit.
- Locate the motor side of the 9 pin plug in the blower compartment.




- A. Cut the white wire 1" from the motor side of the plug and connect the wire from the motor to DC out -, on the adapter. Use a wire nut to cap off the remaining loose white wire from the plug.
- B. Cut the gray wire 1" from the motor side of the plug and connect the wire from the motor to DC out +, on the adapter. Use a wire nut to cap off the remaining loose gray wire from the plug.
- C. Connect the AC in on the adapter to R and C on the normal thermostat terminal block. These terminals are not polarity sensitive. You will have to run a 2-conductor wire a for this connection.



Where to mount the adapter.


Wiring diagram



Plug location in the blower section




Close up of the motor plug



I would use a couple of wire ties to secure the voltage adapter to the motor wires in this location. Position the green connection plug on the top of the control as shown above.

Single Phase UCB




Has 7 dip switches

Fan adjustment for low static

Single Phase UCB

Low speed adjustment



LOW SPEED Dip 1 and Dip 2

Factory set “LOW SPEED” 2 pin DIP:

| LOW SPEED | | % of User Set Fan Speed |
|------------------|-------------|------------------------------------|
| DIP1 | DIP2 | |
| 0 | 0 | 100% |
| 0 | 1 | 88% |
| 1 | 0 | 75% |
| 1 | 1 | 66% |

5-Pin DIP Switch (Single Phase - 3, 4 and 5 ton units only)

On single phase units, the approximate static pressure of the ductwork must be set for optimal unit efficiency. The unit is factory set for greater than 1.0 in. wg. If the external static pressure is less than 1.0 in. wg, slide switch 1 on the 5-pin DIP to the “ON” position. See Fig. 10. Switches 2 and 3 are used to determine the unit tonnage. Switches 4 and 5 are used to match the motor and drive combination. Table 2 details the various settings for the 5-pin DIP switch.




Table 2 — LOW SPEED 5-Pin DIP Switch Reference

| QUICK ENABLE/DISABLE | UNIT TON REFERENCE | | UNIT/MOTOR REFERENCE | | UNIT APPLICATION REFERENCE |
|-------------------------|--------------------|------|----------------------|------|---------------------------------------|
| | DIP2 | DIP3 | DIP4 | DIP5 | |
| DIP1 | DIP2 | DIP3 | DIP4 | DIP5 | |
| 1 | 0 | 1 | 0 | 1 | 3 ton with Low static motor option |
| 1 | 0 | 1 | 1 | 0 | 3 ton with Medium static motor option |
| 1 | 0 | 1 | 1 | 1 | 3 ton with High static motor option |
| 1 | 1 | 0 | 0 | 1 | 4 ton with Low static motor option |
| 1 | 1 | 0 | 1 | 0 | 4 ton with Medium static motor option |
| 1 | 1 | 0 | 1 | 1 | 4 ton with High static motor option |
| 1 | 1 | 1 | 0 | 1 | 5 ton with Low static motor option |
| 1 | 1 | 1 | 1 | 0 | 5 ton with Medium static motor option |
| 1 | 1 | 1 | 1 | 1 | 5 ton with High static motor option |


Single Phase UCB

Factory set "LOW SPEED" 5 pin DIP:

| Quick Enable/Disable | Unit Ton Ref | | Unit Motor Option Ref | | User Set Fan speed set within this range | | Voltage Output during heat | Unit application Ref |
|----------------------|--------------|------|-----------------------|------|--|---------|----------------------------|---------------------------------------|
| | DIP1 | DIP2 | DIP3 | DIP4 | DIP5 | Lower V | | |
| 0 | DC | DC | DC | DC | DC | DC | Switch and POT | N/A - Heat Speed same as Cool speed |
| 1 | 0 | 0 | 0 | 0 | DC | DC | Switch and POT | N/A - Heat Speed same as Cool speed |
| 1 | 0 | 0 | 0 | 1 | DC | DC | Switch and POT | N/A - Heat Speed same as Cool speed |
| 1 | 0 | 0 | 1 | 0 | DC | DC | Switch and POT | N/A - Heat Speed same as Cool speed |
| 1 | 0 | 0 | 1 | 1 | DC | DC | Switch and POT | N/A - Heat Speed same as Cool speed |
| 1 | 0 | 1 | 0 | 0 | DC | DC | Switch and POT | N/A - Heat Speed same as Cool speed |
| 1 | 0 | 1 | 0 | 1 | 8 | 9.5 | 8 | 3 ton with Low static motor option |
| 1 | 0 | 1 | 1 | 0 | 6.9 | 8.2 | 6.9 | 3 ton with Medium static motor option |
| 1 | 0 | 1 | 1 | 1 | 6.1 | 7.2 | 6.1 | 3 ton with High static motor option |
| 1 | 1 | 0 | 0 | 0 | DC | DC | Switch and POT | N/A - Heat Speed same as Cool speed |
| 1 | 1 | 0 | 0 | 1 | 8.6 | 10 | 8.6 | 4 ton with Low static motor option |
| 1 | 1 | 0 | 1 | 0 | 7.5 | 9.7 | 7.5 | 4 ton with Medium static motor option |
| 1 | 1 | 0 | 1 | 1 | 6.6 | 8.5 | 6.6 | 4 ton with High static motor option |
| 1 | 1 | 1 | 0 | 0 | DC | DC | Switch and POT | N/A - Heat Speed same as Cool speed |
| 1 | 1 | 1 | 0 | 1 | 7.9 | 10 | 7.9 | 5 ton with Low static motor option |
| 1 | 1 | 1 | 1 | 0 | 6.9 | 10 | 6.9 | 5 ton with Medium static motor option |
| 1 | 1 | 1 | 1 | 1 | 6.4 | 9.2 | 6.4 | 5 ton with High static motor option |

DC= Don't Care

Three Phase UCB Board



Has 2 dip switches only
LOW SPEED

Factory set "LOW SPEED" 2 pin DIP:

| LOW SPEED | | % of User Set Fan Speed |
|-----------|------|-------------------------|
| DIP1 | DIP2 | |
| 0 | 0 | 100% |
| 0 | 1 | 88% |
| 1 | 0 | 75% |
| 1 | 1 | 66% |

FAN SPEED SET UP:


1 Calculate VDC from CFM and ESP plus field accessories.

2 Connect multimeter

3 Set Switch to A, B, or C from Switch Range chart below.

4 Turn dial to fine tune VDC reading.

5 Fill in Field Setting.



1750 CFM @ 1 inch
ESP
Requires setting of 9.1
VDC

Vdc Calculator

| UNIT MODEL NUMBER | CFM | ESP in. wg | | | | | | |
|-------------------|-----|------------|-----|-----|-----|-----|-----|------|
| | | 0.2 | 0.4 | 0.6 | 0.8 | 1.0 | 1.2 | 1.4 |
| 1500 | | 6.0 | 6.7 | 7.4 | 8.0 | 8.5 | 9.0 | 9.5 |
| 1625 | | 6.3 | 7.1 | 7.7 | 8.3 | 8.8 | 9.3 | 9.7 |
| 1750 | | 6.7 | 7.4 | 8.0 | 8.6 | 9.1 | 9.5 | 10.0 |
| 1875 | | 7.1 | 7.7 | 8.3 | 8.9 | 9.4 | 9.8 | |
| 2000 | | 7.5 | 8.1 | 8.7 | 9.2 | 9.7 | | |
| 2125 | | 7.9 | 8.4 | 9.0 | 9.5 | | | |
| 2250 | | 8.3 | 8.8 | 9.4 | | | | |
| 2375 | | 8.7 | 9.2 | 9.7 | | | | |
| 2500 | | 9.1 | 9.5 | | | | | |

| Field Accessories: | |
|--------------------|---------------------------------|
| Economizer | 0.1 0.1 0.1 0.1 0.1 0.1 0.1 0.1 |
| | |
| | |

Factory Setting:
7.8 Vdc

Field Setting:

Record field setting here
_____ Vdc

Switch Range: *

| | A | B | C |
|---|------------|---|---|
| A | 4.1 - 7.5 | | |
| B | 6.9 - 8.7 | | |
| C | 7.7 - 10.0 | | |

* Overlap in A, B, C switch range designed for maximum field adjustment potential. For example 7.2 can be set at either A or B.

NOTE: Values in the Field Accessories section are VDC adders.

Fig. 9 — Example of Fan Speed Set Up Labels for Electro-Mechanical Controls

Service Manual Information

48FCFA06 THREE PHASE - MEDIUM STATIC — 5 TON HORIZONTAL SUPPLY

| CFM | AVAILABLE EXTERNAL STATIC PRESSURE (in. wg) | | | | | | | | | |
|------|---|-----|------|-----|------|-----|------|-----|------|-----|
| | 0.2 | | 0.4 | | 0.6 | | 0.8 | | 1.0 | |
| | RPM | Vdc | RPM | Vdc | RPM | Vdc | RPM | Vdc | RPM | Vdc |
| 1500 | 1420 | 5.9 | 1593 | 6.7 | 1746 | 7.3 | 1883 | 7.9 | 2008 | 8.4 |
| 1625 | 1509 | 6.3 | 1673 | 7.0 | 1820 | 7.6 | 1954 | 8.2 | 2076 | 8.7 |
| 1750 | 1599 | 6.7 | 1755 | 7.3 | 1897 | 7.9 | 2026 | 8.5 | 2146 | 9.0 |
| 1875 | 1691 | 7.1 | 1839 | 7.7 | 1976 | 8.3 | 2102 | 8.8 | 2218 | 9.3 |
| 2000 | 1784 | 7.5 | 1924 | 8.1 | 2056 | 8.6 | 2178 | 9.1 | 2291 | 9.6 |
| 2125 | 1878 | 7.9 | 2011 | 8.4 | 2137 | 8.9 | 2256 | 9.4 | 2367 | 9.9 |
| 2250 | 1974 | 8.3 | 2099 | 8.8 | 2221 | 9.3 | 2335 | 9.8 | — | — |
| 2375 | 2070 | 8.7 | 2189 | 9.2 | 2305 | 9.6 | — | — | — | — |
| 2500 | 2166 | 9.1 | 2280 | 9.5 | — | — | — | — | — | — |

ECONOMIZERS

Integrated Economizer Basic Operation


When free cooling is not available, the compressors will be controlled by the zone thermostat, the economizer will drive to the minimum position to bring in ventilation air.

When the outdoor air is cool enough, the outdoor air damper is modulated open by the economizer control and the return air damper closes to use the outside air for free cooling. The Y1 signal relay in the economizer control opens keeping the Y1 compressor off.

If the building load is high and Y2 is energized by the zone thermostat, the first stage of mechanical cooling (Y1) will be used to supplement the free cooling provided by the economizer. If mechanical cooling is utilized with free cooling, the outdoor-air damper will remain open, and the Y1 compressor is energized.


Any time the indoor fan comes on, the economizer opens, and the outside air damper moves to the minimum position set up on the control.

The outside air damper is in the minimum position and the return air damper is open.



On a call for cooling, if the outside temperature is not acceptable to use for free cooling:

- The outside air damper drives to the minimum position and the return air damper is open.
- The Y1 circuit thru the economizer control brings on the Y1 compressor.



When the outside air is acceptable enough to be used for cooling.


The outside air damper opens bringing in free cooling.

The return air damper closes, so most of the air is coming from the outside air damper.

When the outside air damper is open the building pressure will start to increase.

The standard economizer has a barometric damper built in to help relieve that pressure build up.

When required a powered exhaust assembly can take the place of barometric style to control building pressure.



The W7212 Economizer control is used in the Economizer IV

W7212 Economizer IV





Fig. 26 - EconoMiSer IV Controller




The EconoMiSer IV assembly is equipped with a low ambient temperature lockout switch located in the outdoor airstream which is used to lock out the compressors below a 42°F (6°C) ambient temperature.

Fig. 1 - EconoMiSer IV Component Locations

POTENTIOMETER DEFAULTS SETTINGS:
 POWER EXH MIDDLE
 MINIMUM POS. FULLY CLOSED
 DCV MAX. MIDDLE
 DCV SET MIDDLE
 ENTHALPY C SETTING

W7212

ECONOMIZER (FIOP/ACCESSORY)




Low ambient temperature lockout switch is mounted in the economizer

ECONOMIZER NOTES:

1. 620 OHM, 1 WATT 5% RESISTER SHOULD BE REMOVED ONLY WHEN USING DIFFERENTIAL ENTHALPY OR DRY BULB.
2. IF A SEPARATE FIELD SUPPLIED 24V TRANSFORMER IS USED FOR THE IAQ SENSOR POWER SUPPLY, IT CANNOT HAVE THE SECONDARY OF THE TRANSFORMER GROUND.
3. FOR FIELD INSTALLED REMOTE MINIMUM POSITION POT, REMOVE BLACK WIRE JUMPER BETWEEN P AND P1 AND SET CONTROL MINIMUM POSITION POT TO THE MINIMUM POSITION.


TO PWR EXHAUST ACCESSORY

When you are installing an economizer remove the bypass plug to connect the economizer to the harness in the unit.
SAVE THIS PLUG! You can use it to bypass an economizer for testing purposes.



50HJ400345 ECONOMIZER BYPASS PLUG


Wiring diagram
Bypass plug
connected to the
PL6 plug in the
unit harness



Remove the filter access door to gain access to the economizer harness



Use a pocket screwdriver and a light touch when adjusting these settings



W7212 Economizer IV Sensors

Table 1 – EconoMiSer IV Sensor Usage

| APPLICATION | ECONOMISER IV WITH OUTDOOR AIR DRY BULB SENSOR | | |
|---|--|----|------------------|
| | Accessories Required | | |
| Outdoor Air Dry Bulb | None. The outdoor air dry bulb sensor is factory installed. | | |
| Differential Dry Bulb | CRTEMPSN002A00* | | |
| Single Enthalpy | HH57AC078 | | |
| Differential Enthalpy | HH57AC078 and CRENTDIF004A00* | | |
| CO ₂ for DCV Control using a Wall-Mounted CO ₂ Sensor | 33ZCSENCO2 or CGCDXSEN004A00† | | |
| CO ₂ for DCV Control using a Duct-Mounted CO ₂ Sensor | 33ZCSENCO2 or CGCDXSEN004A00† and 33ZCASPCO2 or CGCDXASP001A00** | OR | CRCBDIOX005A00†† |

* CRENTDIF004A00 and CRTEMPSN002A00 accessories are used on many different base units. As such, these kits may contain parts that will not be needed for installation.

† 33ZCSENCO2 and CGCDXSEN004A00 are accessory CO₂ sensors.


** 33ZCASPCO2 and CGCDXASP001A00 are accessory aspirator boxes required for duct-mounted applications.

††CRCBDIOX005A00 is an accessory that contains both 33ZCSENCO2 and 33ZCASPCO2 accessories.



NOTE: Some 48/50TC04-012 units may have factory-installed enthalpy sensor.

EconoMi\$er IV Standard Sensors

OUTDOOR AIR TEMPERATURE (OAT) SENSOR — The outdoor air temperature sensor (HH57AC074) is a 10 to 20 mA device used to measure the outdoor-air temperature. The outdoor-air temperature is used to determine when the EconoMi\$er IV can be used for free cooling. The sensor is factory-installed on the EconoMi\$er IV in the outdoor air-stream on 3 to 12½ ton units and must be relocated on 13 to 25 ton units. See Fig. 1 and 15. The operating range of temperature measurement is 40 to 100 F.



Recommended setting for our area



- When you have the economizer that is wide open and it is hot enough outside for it to be closed, you can pull one of the wires off the outside air temperature sensor.
- If the damper starts to drive closed, you have a bad outside air sensor.
- A failed sensor can create a high mA reading to the economizer control which would indicate the outside air is acceptable for free cooling.




Fig. 21 — Outdoor Air Temperature Changeover Set Points

Additional outdoor temperature sensor option that uses dip switches for a set changeover point

C7660 Set Up

See fig. 6.

When outdoor air temperature is below the changeover setpoint, the sensor will provide a 20 mA signal to the economizer which translates to **OK to economize** positioning the damper open on a call for cooling.

When the outdoor air is above the changeover setpoint, the sensor provides a 4 mA signal to the economizer which translates to **not OK to economize** and the outdoor damper drives to minimum position.

The C7660 temperature sensors replace the control function of the temperature changeover in the economizer control.

The A-B-C-D potentiometer on the economizer does not control the changeover point when a C7660 sensor is used in place of an enthalpy sensor. For single dry bulb set the potentiometer to D.

The factory default switch setting is 63°F. the changeover temperature can be field set by changing the positions of the switches using fig. 7.



C101070

Fig. 6 - C7660 Temperature Sensor


| DIP SWITCH POSITION | CHANGEOVER TEMPERATURE |
|---------------------|------------------------|
| ON OFF 1 2 3 | 48°F |
| ON OFF 1 2 3 | 53°F |
| ON OFF 1 2 3 | 55°F |
| ON OFF 1 2 3 | 58°F |
| ON OFF 1 2 3 | 63°F Default |
| ON OFF 1 2 3 | 68°F |
| ON OFF 1 2 3 | 73°F |
| ON OFF 1 2 3 | 78°F |

Fig. 7 - Changeover Switch Set Points

switches to the appropriate temperature required for application. Set the free Cooling/Enthalpy Changeover Set Point potentiometer to "D" located on the face the economizer control.

W7212 Economizer IV

Single Enthalpy Sensor Part # HH57AC078



I recommend using setting D for our area.




Fig. 26 - EconoMiSer IV Controller






Fig. 91 - Enthalpy Changeover Setpoints

W7212 Economizer IV



ECONOMIZER NOTES:

Dry bulb sensor chart



C06035

Fig. 21 - Outdoor Air Temperature Changeover Set Points

Or




Fig. 25 - Enthalpy Changeover Set Points

W7212 Economizer IV

SUPPLY AIR TEMPERATURE (SAT) SENSOR — The supply air temperature sensor is a 3 K thermistor located at the inlet of the indoor fan. See Fig. 9 and 16. This sensor is field installed. The operating range of temperature measurement is 0° to 158 F. See Table 5 for sensor temperature/resistance values.

The temperature sensor looks like an eyelet terminal with wires running to it. The sensor is located in the “crimp end” and is sealed from moisture.








Table 5 — Supply Air Sensor Temperature/Resistance Values

| TEMPERATURE (F) | RESISTANCE (ohms) |
|-----------------|-------------------|
| -58 | 200,250 |
| -40 | 100,680 |
| -22 | 53,010 |
| -4 | 29,091 |
| 14 | 16,590 |
| 32 | 9,795 |
| 50 | 5,970 |
| 68 | 3,747 |
| 77 | 3,000 |
| 86 | 2,416 |
| 104 | 1,597 |
| 122 | 1,080 |
| 140 | 746 |
| 158 | 525 |
| 176 | 376 |
| 185 | 321 |
| 194 | 274 |
| 212 | 203 |
| 230 | 153 |
| 248 | 116 |
| 257 | 102 |
| 266 | 89 |
| 284 | 70 |
| 302 | 55 |

Economizer IV W7212



Economizer IV W7212



W7212 Economizer IV




Fig. 26 - EconoMiSer IV Controller

CO2 Sensor connections
2-10 VDC

Demand Control Ventilation has 2 settings

Maximum open position

CO2 PPM setting

Typical starting point is midway or about 6 VDC for 1000 ppm

Demand Control Ventilation Setpoint

The logic module modulates the outdoor damper to provide ventilation based on the 2-10 Vdc DCV input (AQ-AQ1 terminals). With no cooling signal, the DCV overrides the outdoor air damper when ventilation requires additional outdoor air.

EXAMPLE: CO2 sensor with 2 to 10 Vdc output range 0 to 2000 ppm. Two (2) Vdc is equal to 0 ppm, 10 Vdc is equal to 2000 ppm, threshold is determined to be 1000 ppm. DCV potentiometer to be set at 6 Vdc.

Adjust the potentiometer with a small screwdriver by turning the pot to the fully CCW then fully CW positions to determine the end stops. Set the pot for 6 Vdc in the mid position.

When using powered exhaust with the economizer this setting has to be addressed


EXHAUST SET POINT ADJUSTMENT — The exhaust set point will determine when the exhaust fan runs based on damper position (if accessory power exhaust is installed). The set point is modified with the Exhaust Fan Set Point (EXH SET) potentiometer. See Fig. 20. The set point represents the damper position above which the exhaust fans will be turned on. When there is a call for exhaust, the EconoMi\$er IV controller provides a 45 ± 15 second delay before exhaust fan activation to allow the dampers to open. This delay allows the damper to reach the appropriate position to avoid unnecessary fan overload.

Test and balance usually adjusts this setting.


You can set it to 6 volts for a typical setpoint.

When the voltage to the economizer motor gets to 6 volts, the powered exhaust will activate. (about 50% open)

This keeps the building pressure from becoming too high.




W7212 Economizer IV



Minimum position setting
When the indoor fan comes on the economizer will drive to this setting

Adjusting Minimum Position
The minimum position is defined by the minimum outdoor air flow required in the building during the occupied period.

W7212 Economizer IV




If the powered exhaust is activated this light will be on

• If the CO2 sensor is active and calling for ventilation this light will be on


If the outside air sensor or the enthalpy sensor are calling for free cooling, this light will be on.

W7212 Economizer IV



W7212 Outputs to the Economizer Motor

The motor requires a 24 Volt power supply




W7212 Outputs to the Economizer Motor

Actuator command position is defined in a 2-10 vdc value. 2.0-v is outside air damper position fully-closed (0% open); 10.0-v is damper position fully-open (100% open). See Table 6 to correlate control voltage values to outside air damper opening percentage.

Table 6 – Actuator Voltage vs. Damper Position

| Vdc | % Open | Vdc | % Open | Vdc | % Open |
|-----|--------|-----|--------|------|--------|
| 2.0 | 0 | 4.8 | 35 | 7.6 | 70 |
| 2.4 | 5 | 5.2 | 40 | 8.0 | 75 |
| 2.8 | 10 | 5.6 | 45 | 8.4 | 80 |
| 3.2 | 15 | 6.0 | 50 | 8.8 | 85 |
| 3.6 | 20 | 6.4 | 55 | 9.2 | 90 |
| 4.0 | 25 | 6.8 | 60 | 9.6 | 95 |
| 4.4 | 30 | 7.2 | 65 | 10.0 | 100 |

On an earlier slide we discussed the power exhaust setting of 6 volts.
We can see on this chart 6 volts would be about 50% open.



W7212 Economizer IV




Fig. 26 - EconoMiSer IV Controller

W7220 Economizer X Control

W7220 Economizer X Control

Honeywell W7220 Title 24 compliant economizer control






Table 1. Economizer Module - Left hand terminal blocks.

| Label | Type | Description |
|-----------------------------------|--------------------|---|
| Top Left Terminal Block | | |
| MAT MAT | 20k NTC and COM | Mixed Air Temperature Sensor (polarity insensitive connection) |
| OAT OAT | 20k NTC and COM | Outdoor Air Temperature Sensor (polarity insensitive connection) |
| S-BUS S-BUS | SYLK Bus | Sylk Bus sensor (polarity insensitive connection) |
| Bottom Left Terminal Block | | |
| IAQ 2-10 | 2-10 Vdc | Air Quality Sensor Input (e.g. CO ₂ sensor) |
| IAQ COM | COM | Air Quality Sensor Common |
| IAQ 24V | 24 Vac | Air Quality Sensor 24 Vac Source |
| ACT 2-10 | 2-10 Vdc | Damper Actuator Output (2-10 Vdc) |
| ACT COM | COM | Damper Actuator Output Common |
| ACT 24V | 24 Vac | Damper Actuator 24 Vac Source |

Table 2. Economizer Module - Right hand terminal blocks.


| Label | Type | Description |
|------------------------------------|------------|--|
| Top Right Terminal Block | | |
| | n/a | The first terminal is not used |
| AUX2 I | 24 Vac IN | Shut Down (SD) or Heat (W) Conventional only or Heat Pump Changeover (O/B) in Heat Pump mode. |
| OCC | 24 Vac IN | Occupied / Unoccupied Input |
| E-GND | EGND | Earth Ground - System Required |
| EXH1 | 24 Vac OUT | Exhaust Fan 1 Output |
| AUX1 O | 24 Vac OUT | Programmable: Exhaust fan 2 output or ERV or System Alarm output. |
| Bottom Right Terminal Block | | |
| Y2-I | 24 Vac IN | Y2 in - Cooling Stage 2 Input from space thermostat |
| Y2-O | 24 Vac OUT | Y2 out - Cooling Stage 2 Output to stage 2 mechanical cooling |





See power exhaust installation instructions for connection information.

If using the OA enthalpy accessory, the OAT must be removed. Set sensor dip-switches. See Table 11.

Fig. 10A - Typical Wiring Diagram For 1 and 2 Speed Units (2 Speed Diagram Shown)





1 Either the OAT or the Enthalpy Sensor can be used but not both. Remove OAT if Enthalpy's used.

Supply Air Temperature Sensor

The W7220 controller uses a 20-k ohm analog sensor for Supply Air Temperature (SAT). The thermistor is attached to a ring terminal. The ring terminal is attached to the unit's supply fan housing, downstream of the unit's indoor coil. The SAT sensor is connected to the W7220 input terminals marked MAT. See Table 7 for sensor resistance to temperature correlations.




Fig. 4 - W7220 Sensor and Control I/O Connections

The W7220 controller requires a valid signal from its SAT channel in order to function. If the SAT connection to the W7220 is lost, the W7220 will initiate an alarm condition immediately. No economizing operation will be permitted until this alarm is cleared.


Table 7 – SAT/OAT Sensor Characteristics

| Deg C | Ohms | Deg F | Ohms |
|-------|--------|-------|--------|
| -30 | 415156 | -20 | 386130 |
| -25 | 301540 | 0 | 193070 |
| -20 | 221210 | 20 | 101820 |
| -15 | 163834 | 32 | 70200 |
| -10 | 122453 | 40 | 55420 |
| -5 | 92382 | 45 | 47771 |
| 0 | 70200 | 50 | 41258 |
| 5 | 53806 | 55 | 35725 |
| 10 | 41561 | 60 | 31035 |
| 15 | 32341 | 65 | 27069 |
| 20 | 25346 | 70 | 23719 |
| 25 | 20000 | 77 | 20000 |
| 30 | 15886 | 80 | 18473 |
| 35 | 12698 | 100 | 11544 |
| 40 | 10212 | 120 | 6768 |
| 45 | 8261 | | |
| 50 | 6720 | | |

Supply Air Temperature Sensor

The W7220 controller uses a 20-k ohm analog sensor for Supply Air Temperature (SAT). The thermistor is attached to a ring terminal. The ring terminal is attached to the unit's supply fan housing, downstream of the unit's indoor coil. The SAT sensor is connected to the W7220 input terminals marked MAT. See Table 7 for sensor resistance to temperature correlations.

HH79ZZ007



**Fig. 9 - Supply Air Sensor Placement
(2 to 12-¹/₂ Ton Units)**

C07373

Honeywell - C7250A1001/U 20k Temperature Sensor for Mixed Air (MAT sensor option)






Table 8 – Enthalpy Control Sensor Wiring Terminations^a

| Terminal | | Type | Description |
|----------|-------|-------|--|
| Nbr | Label | | |
| 1 | S-BUS | S-BUS | S-Bus Communications (Enthalpy Control Sensor Bus) |
| 2 | S-BUS | S-BUS | S-Bus Communications (Enthalpy Control Sensor Bus) |

a Terminals are polarity insensitive.

Table 9 – Enthalpy Control Sensor DIP Switch Settings


| Use | DIP Switch Positions for Switches 1, 2, & 3 | | |
|-----------------|---|-----|-----|
| | 1 | 2 | 3 |
| DA ^a | OFF | ON | OFF |
| RA ^b | ON | OFF | OFF |
| OA ^c | OFF | OFF | OFF |

a DA = Discharge Air

b RA = Return Air

c OA = Outside Air

Factory Default is Outside Air



When a S-bus sensor is connected to an existing network, it will take 60 minutes for the network to recognize and auto-configure itself to use the new sensor. During the 60 minute setup period, no alarms for sensor failures (except SAT) will be issued and no economizing function will be available.






Fig. 5 - Actuator/S-BUS

ECONOMIZER IV & X ¹

IF YOU HAVE:

| DESIRED CONTROL METHOD | FIELD INSTALLED DRY BULB ACCESSORY ECONOMIZER IV & X | FACTORY INSTALLED DRY BULB SENSOR ECONOMIZER IV & X | FACTORY INSTALLED ENTHALPY SENSOR ECONOMIZER IV & X |
|---|--|---|---|
| Single Dry Bulb Temperature Control | None: Outside Air dry bulb sensor is factory installed | None: Outside Air dry bulb sensor is factory installed | None: Outside Air dry bulb sensor is factory installed |
| Differential Dry Bulb Temperature Control | N/A on EconoMiSer IV (1)--HH-57AC-081 (EconoMiSer X) | N/A on EconoMiSer IV (1)--HH-57AC-081 (EconoMiSer X) | N/A |
| Single Enthalpy Control | (1)--HH--57AC-078 (EconoMiSer IV) or (1)--HH--57AC-081 (EconoMiSer X) | (1)--HH--57AC-078 (EconoMiSer IV) or (1)--HH--57AC-081 (EconoMiSer X) | None: Outside Air Enthalpy sensor is factory installed |
| Differential Enthalpy Control | (1)--HH--57AC-078 & (1) CRENDIF004A00 (EconoMiSer IV) or (2)--HH-57AC-081 (EconoMiSer X) | (1)--HH--57AC-078 & (1) CRENDIF004A00 (EconoMiSer IV) or (2)--HH-57AC-081 (EconoMiSer X) | (1) CRENDIF004A00 (EconoMiSer IV) or (1)--HH--57AC-081 (EconoMiSer X) |
| To Add CO2 DCV Control with above: | Wall Mount | (1) 33ZCSPTCO2LCD-01 ⁶ or 33ZCSPTCO2-01 ⁶ | |
| | Duct Mount | (1) 33ZCSPTCO2LCD-01 ⁶ or 33ZCSPTCO2-01 ⁶ & (1) 33ZCASPCO2 or (1) CRCBDIOX005A00 ³ | |

Economizer IV
W7212

Economizer X
W7220

Honeywell W7220 Title 24 compliant economizer control





| OA Good to economize? | Y1-I | Y2-I | FAN SPD | Y1-O | Y2-O | Occupied | Unoccupied |
|------------------------------|-------------|-------------|----------------|-------------|----------------------|----------------------|---------------------|
| No | Off | Off | High | 0-v/Off | 0-v/Off | MIN POS | Closed |
| | On | Off | High | 24-v/On | 0-v/Off | MIN POS | Closed |
| | On | On | High | 24-v/On | 24-v/On | MIN POS | Closed |
| Yes | Off | Off | High | 0-v/Off | 0-v/Off | MIN POS | Closed |
| | On | Off | High | 0-v/Off | 0-v/Off | MIN POS to Full-Open | Closed to Full-Open |
| | On | On | High | 24-v/On | 0-v/Off ^a | MIN POS to Full-Open | Closed to Full-Open |

| OA Good to economize? | Y1-I | Y2-I | FAN SPD | Y1-O | Y2-O | Occupied | Unoccupied |
|------------------------------|-------------|-------------|----------------|-------------|----------------------|----------------------|---------------------|
| No | Off | Off | High | 0-v/Off | 0-v/Off | MIN POS | Closed |
| | On | Off | High | 24-v/On | 0-v/Off | MIN POS | Closed |
| | On | On | High | 24-v/On | 24-v/On | MIN POS | Closed |
| Yes | Off | Off | High | 0-v/Off | 0-v/Off | MIN POS | Closed |
| | On | Off | High | 0-v/Off | 0-v/Off | MIN POS to Full-Open | Closed to Full-Open |
| | On | On | High | 24-v/On | 0-v/Off ^a | MIN POS to Full-Open | Closed to Full-Open |

Circuit for the W7220 to open the economizer to the minimum position

IGC fan signal returns on black



Honeywell W7220 Title 24 compliant economizer control

W7220

To check out the operation of the W7220:

Use the Checkout menu in the table below to test the damper operation and any configured outputs. Only items that are configured are shown in the Checkout menu.

1. Scroll to the desired test in the Checkout menu using the ▲ and ▼ buttons.
2. Press the ↵ button to select the item.
3. RUN? appears.
4. Press the ↵ button to start the test.
5. The unit pauses and then displays IN PROGRESS.
6. When the test is complete, DONE appears.
7. When all parameters have been tested, press the ⏪ button (Menu up) to end the test (e.g. turn off the relay).



The checkout tests can all be performed at the time of installation or any time during the operation of the system.

TROUBLESHOOTING

Alarms

The Economizer module provides alarm messages that display on the 2-line LCD.

NOTE: JADE will be in the “set up” mode for the first 60 minutes after powered. If a sensor for OA air or Sylkbus device (sensor, actuator) is disconnected during the set up mode, the JADE will not alarm that failure. The MA sensor is a system “critical” sensor; if the MA sensor is removed during the set up mode, the JADE will alarm. After 60 minutes the JADE controller will change to operation mode and all components removed or failed will alarm in the operation mode.

You can also navigate to the Alarms menu at any time.

Clearing Alarms

Once the alarm has been identified and the cause has been removed (e.g. replaced faulty sensor), the alarm can be cleared from the display.


To clear an alarm, perform the following:

1. Navigate to the desired alarm.
2. Press the ← button.
3. ERASE? displays.
4. Press the ← button.
5. ALARM ERASED displays.
6. Press the ⬆ button (MenuUp/Exit) to complete the action and return to the previous menu.



| | | | | |
|------------------------------------|------------|---------|--|--|
| SETPOINTS | MAT SET | 53°F | 38 to 70 °F; increment by 1 | The economizer will modulate the OA damper to maintain the mixed air temperature at the setpoint. |
| | LOW T LOCK | 32°F | -45 to 80 °F; increment by 1 | Setpoint determines outdoor temperature when the mechanical cooling cannot be turned on. Commonly referred to as the Compressor lockout. At or below the setpoint the Y1-O and Y2-O will not be energized on the controller. |
| | DRYBLB SET | 63°F | 48 to 80 °F; increment by 1 | <i>Dry bulb setpoint will only appear if using dry bulb change over.</i> Setpoint determines where the economizer will assume outdoor air temperature is good for free cooling; e.g.; at 63 °F setpoint unit will economize at 62 °F and below and not economize at 64 °F and above. There is a 2 °F deadband. |
| | ENTH CURVE | ES3 | ES1, ES2, ES3, ES4, or ES5 | <i>ES curve will only appear if using enthalpy changeover.</i> Enthalpy boundary "curves" for economizing using single enthalpy. See page 11 for description of enthalpy curves. |
| | DCV SET | 1100ppm | 500 to 2000 ppm increment by 100 | Displays ONLY if a CO2 sensor is connected. Setpoint for Demand Control Ventilation of space. Above the setpoint, the OA dampers will modulate open to bring in additional OA to maintain a space ppm level below the setpoint. |
| | MIN POS | 2.8 V | 2 to 10 Vdc | Displays ONLY if a CO2 sensor is NOT connected. With 2-speed fan units MIN POS L (low speed fan) and MIN POS H (high speed fan) settings are required. Default for MIN POS L is 3.2V and MIN POS H is 2.8V. |
| | VENTMAX | 2.8 V | 2 to 10 Vdc | Displays only if a CO2 sensor is connected. Used for Vbz (ventilation max cfm) setpoint. VENTMAX is the same setting as MIN POS would be if you did not have the CO2 sensor. |
| | | | 100 to 9990 cfm increment by 10 | If OA, MA RA and CO2 sensors are connected and DCV CAL ENABLE is set to AUTO mode, the OA dampers are controlled by CFM and displays from 100 to 9990 cfm. |
| | | | 2 to 10 Vdc | With 2-speed fan units VENTMAX L (low speed fan) and VENTMAX H (high speed fan) settings are required. Default for VENTMAX L is 3.2V and VENTMAX H is 2.8V. |
| | VENTMIN | 2.25 V | 2 to 10 Vdc | Displays only if CO2 sensor is connected. Used for Va (ventilation min cfm) setpoint. This is the ventilation requirement for less than maximum occupancy of the space. |
| 100 to 9990 cfm increment by 10 | | | If OA, MA RA and CO2 sensors are connected and DCV CAL ENABLE is set to AUTO mode, the OA dampers are controlled by CFM and displays from 100 to 9990 cfm. | |
| 2 to 10 Vdc | | | With 2-speed fan units VENTMIN L (low speed fan) and VENTMIN H (high speed fan) settings are required. Default for VENTMIN L is 2.5V and VENTMIN H is 2.25V. | |


Honeywell W7220 Economizer Control, the following steps show how to increase the minimum position for low speed fan from 3.20 volts to 3.25 volts



Increasing the volt setting will open the damper a little more and increase outside air CFM.







The adjustable range is from 2 volts (closed) to 10 volts (wide open)




Honeywell

W7220 ↓
STATUS ██████████




W7220 Economizer X Mounting Location



W 7220 STATUS



Select the enter
Button



Use the arrows to
scroll thru the sensors
and outputs




Checkout Tests

Use the Checkout menu (Table 5) to test the damper operation and any configured outputs. Only items that are configured are shown in the Checkout menu.

NOTE: See “Interface Overview” on page 18. for information about menu navigation and use of the keypad.

To perform a Checkout test:

1. Scroll to the desired test in the Checkout menu using the ▲ and ▼ buttons.
2. Press the ↵ button to select the item.
3. RUN? appears on the display.
4. Press the ↵ button to start the test.
5. The unit pauses and then displays IN PROGRESS.
6. When all parameters have been tested, press the  button (Menu up) to end the test (e.g. turn off the relay).

The checkout tests can all be performed at the time of installation or any time during the operation of the system as a test that the system is operable.

W 7220 CHECKOUT




Checkout Menu

| Checkout Item | Checkout Test |
|----------------|---|
| DAMPER VMIN-HS | Positions damper to VMIN position |
| DAMPER VMAX-HS | Positions damper to VMAX position |
| DAMPER OPEN | Positions damper to the full open position. Exhaust fan contacts enable during the DAMPER OPEN test. Make sure you pause in this mode to allow for exhaust contacts to energize due to the delay in the system. |
| DAMPER CLOSE | Positions damper to the fully closed position. |
| CONNECT Y1-O | Closes the Y1-O relay (Y1-O). See CAUTION on this page |
| CONNECT Y2-O | Closes the Y2-O relay (Y2-O). See CAUTION on this page |
| CONNECT AUX | Energizes the AUX output. If Aux setting is: <ul style="list-style-type: none">• NONE – no action taken• ERV – 24 Vac out. Turns on or signals an ERV that the conditions are not good for economizing but are good for ERV operation.⁹• SYS – 24 Vac out. Issues a system alarm. |

The following slides have additional information related to the control circuits


Typical 48-50TC and 48-50HC Wiring

If you have an economizer hooked up but you want to bypass the economizer circuit to check both stages of cooling, you can insert jumpers in the back of the economizer plug on the main control board.




When you finish testing make sure you remove the wires, so the economizer is back in control.


48-50 FC Economizer Circuit




48FC 08-14 IFM ties into the 24 Volt safety circuit



WeatherMaker® 48FC**20-30 Single Package Rooftop with Gas Heat/Electric Cooling




Twin Indoor Fan motors are tied into the 24 Volt safety circuit



8. ON HORIZONTAL SUPPLY UNITS, IFM2 GRA AND WHT WIRES WILL INCLUDE IN-LINE RESISTORS TO REDUCE IT'S SPEED.

New Economizer System

SIEMENS




POL224.00, POL224.05

Economizer RTU



Features

- Flexible sensor inputs accept Type II NTC 10K standard sensors, or Siemens QFM2160U or QFR9530 combination temperature/humidity sensor for enthalpy control
- Can be used with Siemens OpenAir® damper actuator GQD, GMA or GCA series
- 24Vac digital inputs for indication of occupancy, 3-stage Cooling Stage input, Shutdown, Heat Conventional, Heat Pump Changeover or Preoccupancy
- 24Vac relay outputs (digital) for 3-stage Cooling Stage output, Exhaust Fan, VFD On/Off (Variable Speed Supply Fan Enable), System Alarm output (Title 24) or Energy Recovery Ventilation (ERV)
- Anti-freeze protection
- Fault detection and alarming
- Brownout protection
- “Free cooling” based on single or dual dry bulb temperature, or combination temperature + humidity sensors
- Automatic switch-over for different control modes
- Parameter settings based on climate zone, using GPS functionality in the Climatix Mobile application
- LED indication for free cooling operation, sensor operation and damper operation
- Quick installation and easy commissioning with Climatix Mobile application
- User Interface for normal operation, parameter setup and alarm notifications with an LCD display and three operation buttons
- RS485 port for BACnet MSTP or Modbus RTU communication
- USB interface for firmware updates and WLAN connection
- QR codes for quick access to download Climatix Mobile application and user documentation





OAT NTC10K



MAT/DAT NTC10K



Mobile Application



Controller Password

Relevant data for POL224.00 Economizer commissioning:

- Username: Administrator
- Initial Password: OneBT
- Once logged in to the controller, a password change will be required to proceed with the commissioning process.

Accessories

A WLAN stick needs to be connected to the product via the USB host interface during commissioning with the Climatix Mobile application.

| Type of unit | Product no. | Datasheet* |
|--------------|-----------------------------------|------------|
| WLAN stick | POL903.00/100 S55803-Y130-A100 | CC1N7219en |



Relevant data for WLAN commissioning:

- SSID: Siemens-WLAN-Stick
- Password: SIBPAdmin
- DNS name: siemens.wlanstick

Siemens AG recommends changing the password as part of the commissioning process. Changes to all settings can be made via the web interface as required.

Any
Questions

ms.techsup@carrierenterprise.com